

# HyperWorks Tips + Tricks

## Output H3d file each Subcase

### Product: OptiStruct/HyperMesh

**Product Version:** 12.0 and above

#### Topic Objective

Writes out H3d files for each subcase from an Analysis.

#### Topic Details

To request H3d file for each subcase if exists in model for an analysis, create an output request.

Go to Control Cards→Output→H3D→ALL→BySub

